SONY

4-465-169-**32**(1)

Wireless Stereo Headset

Reference Guide	GB
參考指南	CT
참조 가이드	KR

제조연월: |

MDR-AS700BT

©2013 Sony Corporation Printed in China

http://www.sony.net/

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

The BLUETOOTH word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.

The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

Microsoft, Windows and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Macintosh and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries.

Other trademarks and trade names are those of their respective owners.

Complies with IDA Standards DB00353

Location of the nameplate

The nameplate is placed as shown below.



Precautions

On BLUETOOTH communication

- BLUETOOTH wireless technology operates within a range of about 10 meters. Maximum communication range may vary depending on obstacles (human body, metal, wall, etc.) or electromagnetic environment.
- The antenna is built into the unit as illustrated in the dotted line. The sensitivity of the BLUETOOTH communication will improve by turning the direction of the built-in antenna to the connected BLUETOOTH device. The communication distance shortens when the obstacles are between the antenna of the connected device and this unit.



- The following conditions may affect the sensitivity of BLUETOOTH communication.
  - There is an obstacle such as a human body, metal, or wall between this unit and BLUETOOTH device.
  - A device using 2.4 GHz frequency, such as a wireless LAN device, cordless telephone, or microwave oven, is in use near this unit.
- Because BLUETOOTH devices and wireless LAN (IEEE802.11b/g) use the same frequency, microwave interference may occur and resulting in communication speed deterioration, noise, or invalid connection if this unit is used near a wireless LAN device. In such a case, perform the following.
  - Use this unit at least 10 m away from the wireless LAN device.
  - If this unit is used within 10 m of a wireless LAN device, turn off the wireless LAN device.
  - Install this unit and BLUETOOTH device as near to each other as possible.
- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
  - where inflammable gas is present, in a hospital, train, airplane, or a petrol station
  - near automatic doors or a fire alarm
- This unit supports security capabilities that comply with the BLUETOOTH standard to provide a secure connection when the BLUETOOTH wireless technology is used, but security may not be enough depending on the setting. Be careful when communicating using BLUETOOTH wireless technology.
- We do not take any responsibility for the leakage of information during BLUETOOTH communication.
- Connection with all BLUETOOTH devices cannot be guaranteed.
  - A device featuring BLUETOOTH function is required to conform to the BLUETOOTH standard specified by Bluetooth SIG, Inc. and be authenticated.
  - Even if the connected device conforms to the above mentioned BLUETOOTH standard, some devices may not be connected or work correctly, depending on the features or specifications of the device.
  - While talking on the phone hands free, noise may occur, depending on the device or communication environment.
- Depending on the device to be connected, it may require some time to start communication.

On charging the unit

- This unit can be charged using USB only. Personal computer with USB port is required for charging.
- The unit does not work during charging.

On the splash-proof feature

- The unit has the splash-proof feature and is protected against water splashing from any direction. However, because the unit cannot be used in water, note the following cautions.
  - Make sure that the USB jack cover is closed when you use the unit.
  - Do not use the unit in a humid place such as a bathroom or sauna.
  - In case the unit gets wet, wipe it with a dry cloth and leave the unit until it gets dry before using.

If you cannot operate the unit

- Set the unit in charging status, then press the POWER and VOL – buttons simultaneously. The unit will be reset. Pairing information is not deleted.



- If you are still unable to operate the unit even after the resetting operation above, initialize the unit as follows.
  Turn off the unit by pressing the POWER button for more than 2 seconds. Then, hold the POWER button down for more than 15 seconds. The indicator (blue) flashes 4 times, and the unit is reset to the factory settings. All pairing information is deleted.

Others

- Do not place this unit in a place exposed to humidity, dust, soot or steam, subject to direct sunlight, or in a car waiting at a traffic signal. It may cause a malfunction.
- Using the BLUETOOTH device may not function on mobile phones, depending on radio wave conditions and location where the equipment is being used.
- If you experience discomfort after using the BLUETOOTH device, stop using the BLUETOOTH device immediately. Should any problem persist, consult your nearest Sony dealer.
- Listening with this unit at high volume may affect your hearing. For traffic safety, do not use this unit while driving or cycling.
- Do not put weight or pressure on this unit as it may cause the unit to deform during long storage.
- Do not subject the unit to excessive shock.
- Clean the unit with a soft dry cloth.
- The earpads may deteriorate due to longterm storage or use.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Specifications

General

Communication System: BLUETOOTH Specification version 3.0
Output: BLUETOOTH Specification Power Class 2
Maximum communication range: Line of sight approx. 10 m[1)]
Frequency band: 2.4 GHz band (2.4000 GHz - 2.4835 GHz)
Modulation method: FHSS
Compatible BLUETOOTH Profiles[2)]:
A2DP (Advanced Audio Distribution Profile)
AVRCP (Audio Video Remote Control Profile)
HFP (Hands-free Profile)
HSP (Headset Profile)
Supported Codec[3)]: SBC[4)], AAC[5)]
Supported content protection method: SCMS-T
Transmission range (A2DP): 20 Hz - 20,000 Hz (Sampling frequency 44.1 kHz)
Included items:
Wireless stereo headset (1)
Micro-USB cable (approx. 50 cm) (1)
Reference Guide (this sheet) (1)
Quick Start Guide (1)
Other documents (1 set)

1) The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.
2) BLUETOOTH standard profiles indicate the purpose of BLUETOOTH communication between devices.
3) Codec: Audio signal compression and conversion format
4) Subband Codec
5) Advanced Audio Coding

Wireless Stereo Headset

Power source: DC 3.7 V: Built-in lithium-ion rechargeable battery
Mass: Approx. 80 g
Operating temperature: 0 °C to 40 °C
Rated power consumption: 1.4 W
Usage hours:
Communication time (including music playback time): Max. 9 hours
Standby time: Max. 120 hours
Charging time:
Approx. 1.5 hours
Charging temperature: 5 °C to 35 °C

Receiver

Type: Open air
Driver units: 30 mm
Frequency response: 10 Hz - 24 kHz

Microphone

Type: Electret condenser
Direction characteristic: Omni directional
Effective frequency range: 100 Hz – 4,000 Hz

System requirements for battery charge using USB

Personal Computer with pre-installed with any of the following operating systems and USB port:

Operating Systems
(when using Windows)
Windows® 8 / Windows® 8 Pro
Windows® 7
Home Basic / Home Premium / Professional / Ultimate
Windows Vista® (Service Pack 2 or later)
Home Basic / Home Premium / Business / Ultimate
Windows® XP (Service Pack 3 or later)
Home Edition / Professional / Media Center Edition 2004 / Media Center Edition 2005

(when using Macintosh)
Mac OS X (version.10.3 or later)

Design and specifications are subject to change without notice.

繁體中文

警告

為減少觸電的危險，請勿打開裝置外殼。請只委託合格的人員進行維修。

請勿將本系統安放在書櫥或壁櫥等狹窄封閉處。

請勿將電池（安裝的電池組或電池）長時間暴露在如陽光或火源等類似過熱的地方。

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

僅適用於台灣

廢電池請回收

BLUETOOTH字樣與商標為Bluetooth SIG, Inc.所擁有；Sony Corporation針對此類標示的使用已獲得授權。

N字標示為NFC Forum, Inc.在美國和其他國家的商標或註冊商標。

Microsoft、Windows及Windows Vista是Microsoft Corporation在美國及/或其他國家的註冊商標或商標。

Macintosh和Mac OS是Apple Inc.在美國及其他國家的註冊商標。

其他商標和商標名稱為其各自所有人擁有。

銘牌位置

以下顯示銘牌位置。



預防措施

關於BLUETOOTH通訊

- BLUETOOTH無線技術的操作範圍約為10公尺。最大的通訊範圍可能會因障礙物（人體、金屬、牆壁等），或電磁場環境而異。
- 虛線表示本機內建的天線。BLUETOOTH通訊的靈敏度可藉由旋轉內建天線的方向到所連接的BLUETOOTH裝置而獲得改善。若所連接的裝置的天線與本機之間有障礙物時，通訊距離將縮短。



- 以下情況可能會影響BLUETOOTH通訊的靈敏度。
  - 本機與BLUETOOTH裝置之間具有障礙物，例如，人體、金屬或牆壁。
  - 在靠近本機的地方使用2.4 GHz頻率的裝置，例如，無線LAN裝置、無線電話或微波爐等。
- 由於BLUETOOTH裝置及無線LAN（IEEE802.11b/g）使用相同的頻率，如果在靠近無線LAN裝置附近使用本裝置的話，可能會發生微波干擾並造成通迅速度衰減、雜訊或連接無效。如果發生這種情況，請執行以下操作。
  - 在距離無線LAN裝置至少10 m遠的地方使用本機。
  - 如果在無線LAN裝置10 m以內的地方使用本機，請關閉無線LAN裝置。
  - 盡可能近地安裝本機與BLUETOOTH裝置。
- 來自BLUETOOTH裝置所放射的微波會影響電子醫療設備的運作。在以下場所，請關閉本機與其他BLUETOOTH裝置，因為這可能會造成意外：
  - 存在可燃性氣體的地方，在醫院、火車、飛機或加油站
  - 在接近自動門或火災警報器的地方
- 本機支援符合BLUETOOTH標準的安全功能，可在使用BLUETOOTH無線技術時提供安全的連線，但安全性可能有所不足，此需視設定而定。使用BLUETOOTH無線技術通訊時，請務必小心。
- 對於在BLUETOOTH通訊期間洩漏的資訊，我們概不負責。
- 無法保證可與所有BLUETOOTH裝置連線。
  - 具備BLUETOOTH功能的裝置需要符合Bluetooth SIG, Inc.指定並獲得驗證的BLUETOOTH規格。
  - 即使所連接的裝置符合上述BLUETOOTH標準，某些裝置也可能無法正確連接或運作，這需視裝置的功能與規格而定。
  - 視裝置與通訊環境而定，以免持方式通話時，可能會出現噪音。
- 視要連接的裝置而定，可能需要一點時間才能開始通訊。

關於為本機充電

- 僅可使用USB為本機充電。需要帶有USB連接埠的個人電腦才能充電。
- 本機在充電期間無法運作。

關於防潑水特性

- 本機具備防潑水特性，可保護來自任何方向的潑水。但是因為本機無法在水中使用，請注意以下事項。
  - 當您使用本機時，請確保USB插頭蓋已經合上。
  - 切勿在潮濕地點使用本機，例如，浴室或三溫暖。
  - 如果本機沾濕，請使用乾布擦拭，並等待其乾燥後再使用。

如果您無法操作本機

- 設定本機操作狀態，然後同時按下POWER與VOL –按鈕。本機將重設。不會刪除配對資訊。



- 完成上述重設操作後，如果您還是無法操作本機，請依下列方式對本機進行初始化。
  按住POWER按鈕超過2秒以關閉本機。然後，往下按住POWER按鈕超過15秒。指示燈（藍色）將閃爍4次，此時本機將重設回出廠設定。所有配對資訊皆被刪除。

其他

- 切勿將本機放置在暴露於濕氣、灰塵、油煙或蒸汽的地方，或使其受陽光直射，或在等待交通號誌的車內。這可能會造成故障。
- 視無線電波條件以及使用設備的地點而定，在行動電話上使用的BLUETOOTH裝置可能無法運作。
- 如果您在使用BLUETOOTH裝置後感覺到不適，請立即停止使用BLUETOOTH裝置。如果問題持續存在，請諮詢您最近的Sony經銷商。
- 以高音量聆聽本機可能會影響您的聽力。基於交通安全，切勿在開車或騎車時使用本機。
- 切勿在本機上放置重物或施加壓力，因為這可能造成本機在長期存放後變形。
- 切勿讓本機受到劇烈撞擊。
- 請使用軟乾布清潔本機。
- 長期存放或使用後，耳墊可能會褪色。
- 如果您有任何本手冊中未涵蓋的與使用本機方面相關的疑問或問題，請諮詢您最近的Sony經銷商。

規格

一般

通訊系統：BLUETOOTH規格3.0版
輸出：BLUETOOTH規格電力等級2
最大通訊範圍：在視線內約10 m[1)]
頻率頻段：2.4 GHz頻段（2.4000 GHz - 2.4835 GHz）
調解方法：FHSS
相容於BLUETOOTH設定檔[2)]：
　A2DP（進階音訊流通設定檔）
　AVRCP（音訊/視訊遙控控制設定檔）
　HFP（免持設定檔）
　HSP（耳機設定檔）
支援的Codec[3)]：SBC[4)]、AAC[5)]
支援的內容保護方法：SCMS-T
傳輸範圍（A2DP）：20 Hz - 20000 Hz（取樣頻率44.1 kHz）
隨附項目：
　無線立體耳機（1）
　Micro-USB纜線（約50 cm）（1）
　參考指南（本頁）（1）
　快速入門指南（1）
　其他文件（1份）

1) 依裝置之間的障礙物、微波爐周圍的磁場、靜電、接收靈敏度、天線效能、作業系統、軟體應用程式等因素而定，實際的距離將有所差異。
2) BLUETOOTH標準設定檔指出了在裝置之間的BLUETOOTH通訊目的。
3) Codec：音訊訊號壓縮與轉換格式
4) 次頻Codec
5) 進階音訊編碼

無線立體耳機

電源：DC 3.7 V：內建鋰離子充電電池
重量：約80 g
操作溫度：0℃至40℃
額定電力消耗：1.4 W
可使用時數：
　通訊時間（包含音樂播放時間）：最長9小時
　待機時間：最長120小時
充電時間：約1.5小時
充電溫度：5℃至35℃

接收器

類型:開放式
驅動器單元：30 mm
頻率響應：10 Hz - 24 kHz

麥克風

類型：電容麥克風
方向特性：全指向式
有效頻率範圍：100 Hz - 4000 Hz

使用USB時的電池充電系統需求

預先安裝以下作業系統且包含USB連接埠的個人電腦：

作業系統
(使用Windows時)
Windows® 8 / Windows® 8 Pro
Windows® 7
Home Basic / Home Premium / Professional / Ultimate
Windows Vista®（包含Service Pack 2或更新版本）
Home Basic / Home Premium / Business / Ultimate
Windows® XP（包含Service Pack 3或更新版本）
Home Edition / Professional / Media Center Edition 2004 / Media Center Edition 2005

(使用Macintosh時)
Mac OS X（10.3版或更新版本）
規格可能有所變更，恕不另行通知。

한국어

경고

모델명: MDR-AS700BT

기자재명: 특정소출력 무선기기(무선데이터통신시스템용 무선기기)

제조연월: 커버에 표시

상호명: 소니코리아(주)

제조자/제조국가: Sony Corporation / China

해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다.

**감전될 염려가 있으므로 캐비닛을 열지 마십시오.
점검은 반드시 기술자에게 의뢰하여 주십시오.**

책장이나 붙박이 캐비닛과 같은 제한된 공간에는 본 장치를 설치하지 마십시오.

배터리(배터리 팩 또는 설치된 배터리)를 햇빛, 불 등과 같은 과도한 열에 장시간 노출시키지 마십시오.

BLUETOOTH 워드마크 및 로고는 Bluetooth SIG, Inc.의 소유이며 Sony Corporation은 라이선스에 따라 사용하고 있습니다.

N 마크는 미국 및 기타 국가에서 NFC Forum, Inc.의 상표 또는 등록 상표입니다.

Microsoft, Windows 및 Windows Vista는 미국 및/또는 기타 국가에서 Microsoft Corporation의 등록 상표 또는 상표입니다.

Macintosh 및 Mac OS는 미국 및 기타 국가에 등록된 Apple Inc.의 상표입니다.

그 밖의 상표 및 상표명은 해당 소유자의 상표 또는 상표명입니다.

명판 위치

명판은 다음의 위치에 있습니다.



사용상의 주의

BLUETOOTH 통신에 대하여

- **BLUETOOTH 무선 기술은 약 10 m 범위 내에서 작동합니다. 최대 통신 가능 범위는 장애물(인체, 금속, 벽 등) 또는 전자 환경에 따라 달라집니다.**
- **안테나는 그림의 점선 표시된 곳에 내장되어 있습니다. 내장 안테나 방향을 연결한 BLUETOOTH 장치 쪽으로 변경하면 BLUETOOTH 통신 감도가 높아집니다. 연결한 장치의 안테나와 본 기기 사이에 장애물이 있으면 통신 가능 거리가 짧아집니다.**



- **다음과 같은 조건은 BLUETOOTH 통신 감도에 영향을 미칠 수 있습니다.**
  - **본 기기와 BLUETOOTH 장치 사이에 인체나 금속, 벽 같은 장애물이 있는 경우.**
  - **본 기기 가까이에서 무선 LAN 장치, 무선 전화기, 전자레인지 등의 2.4 GHz 주파수를 사용하는 장치를 사용하는 경우.**
- **BLUETOOTH 장치 및 LAN(IEEE802.11b/g)은 동일한 주파수를 사용하기 때문에 본 기기를 무선 LAN 장치 가까이에서 사용하면 전파 간섭이 발생해 통신 속도가 저하하거나 노이즈가 발생하거나 또는 연결할 수 없게 될 가능성이 있습니다. 그런 경우는 다음과 같은 대책을 강구하십시오.**
  - **본 기기를 무선 LAN 장치에서 10 m 이상 떨어진 곳에서 사용하십시오.**
  - **무선 LAN 장치에서 10 m 이내에서 본 기기를 사용하고 있을 때에는 무선 LAN 장치 전원을 끄십시오.**
  - **본 기기와 BLUETOOTH 장치는 가능한 한 가까이 설치하십시오.**
- **BLUETOOTH 장치에서 발생되는 전자파는 전자 의료기기의 작동에 영향을 미칠 가능성이 있습니다. 다음과 같은 장소에서는 사고 원인이 될 수 있으므로 본 기기 및 다른 BLUETOOTH 장치의 전원을 끄십시오.**
  - **인화성 가스가 있는 장소, 병원, 기차, 비행기 안이나 주유소**
  - **자동문이나 화재경보기 근처**
- **본 기기는 BLUETOOTH 무선 기술을 사용할 때 안전한 연결을 제공하기 위한 BLUETOOTH 기준에 적합한 보안 기능을 지원하지만 연결 방법에 따라서는 보안이 충분하지 않을 수 있습니다. BLUETOOTH 무선 기술을 사용해 통신할 때에는 주의하십시오.**
- **당사는 BLUETOOTH 통신 중의 정보 누출에 대해 책임지지 않습니다.**
- **모든 BLUETOOTH 장치에 대한 연결을 보증하지는 않습니다.**
  - **BLUETOOTH 기능을 탑재한 장치는 Bluetooth SIG, Inc.가 정한 BLUETOOTH 규격에 적합하고 인증을 받아야 합니다.**
  - **연결한 장치가 위에서 언급한 BLUETOOTH 규격에 적합해도 일부 장치의 기능이나 주요 제원에 따라서는 연결되지 않거나 정상으로 작동하지 않는 경우가 있습니다.**
  - **장치나 통신 환경에 따라서는 핸즈프리로 통화 중에 노이즈가 발생할 수 있습니다.**
- **연결하는 장치에 따라서는 통신 시작까지 다소 시간이 걸릴 수 있습니다.**

본 기기의 충전에 대하여

- **본 기기는 USB에서만 충전할 수 있습니다. 본 기기를 충전하려면 USB 포트가 있는 컴퓨터가 필요합니다.**
- **충전 중에는 본 기기가 작동하지 않습니다.**

방적 기능에 대하여

- **본 기기에는 방적 기능이 탑재되어 있으며 어떤 방향에서 물이 튀어도 작동에는 영향을 받지 않습니다. 하지만 수중에서는 본 기기를 사용할 수 없으므로 다음 사항에 주의하십시오.**
  - **본 기기를 사용할 때 USB 단자 커버가 닫혀있는지 확인하십시오.**
  - **욕실이나 사우나 등 습도가 높은 장소에서 본 기기를 사용하지 마십시오.**
  - **본 기기가 젖었을 때에는 마른 헝겊으로 닦아내고 마를 때까지 기다렸다가 사용하십시오.**

본 기기를 조작할 수 없는 경우

- **본 기기를 충전 상태로 했다가 POWER 버튼과 VOL - 버튼을 동시에 누르십시오. 본 기기가 재설정됩니다. 페어링 정보는 삭제되지 않습니다.**



- **상기 재설정 조작을 해도 본 기기를 조작할 수 없을 때에는 다음 절차에 따라 본 기기를 초기화하십시오.
  POWER 버튼을 2초 이상 눌러서 본 기기 전원을 끄십시오.
  다음은 POWER 버튼을 15초 이상 누르고 있으십시오. 표시등(파란색)이 4번 깜박이고 본 기기가 공장 출하시의 설정으로 재설정됩니다. 모든 페어링 정보가 삭제됩니다.**

기타

- **습도나 먼지, 그을음, 증기가 있는 장소나 직사광선이 닿는 장소, 교통 신호 대기 중인 자동차 안에 본 기기를 두지 마십시오. 고장의 원인이 됩니다.**
- **전파 상태나 본 기기를 사용하는 장소에 따라서는 BLUETOOTH 장치를 사용해도 휴대폰에서 기능이 작동하지 않을 수 있습니다.**
- **BLUETOOTH 장치를 사용하면 불쾌감이 나타날 때에는 즉시 BLUETOOTH 장치의 사용을 중지하십시오. 문제가 해결되지 않을 때에는 가까운 Sony 대리점에 문의하십시오.**
- **큰 음량으로 본 기기를 사용하면 청각에 영향을 미칠 수 있습니다. 교통 안전을 위해 운전 중이나 자전거를 타는 동안에는 본 기기를 사용하지 마십시오.**
- **장기간 보관할 때에는 본 기기의 변형 원인이 되므로 본 기기 위에 무거운 물건을 올려놓거나 눌러놓지 마십시오.**
- **본 기기에 강한 충격을 가하지 마십시오.**
- **본 기기는 부드러운 마른 헝겊으로 청소하십시오.**
- **이어패드는 장기간 보관하거나 사용하면 품질이 저하할 수 있습니다.**
- **이 설명서에 기재되지 않은 본 기기에 관한 문의 사항이나 문제점은 가까운 Sony 대리점에 문의하십시오.**

주요 제원

일반

**통신 시스템: BLUETOOTH Specification Version 3.0
출력: BLUETOOTH Specification Power Class 2
최대 통신 가능 범위: 가시거리 약 10 m[1)]
주파수 대역: 2.4 GHz 대역(2.4000 GHz - 2.4835 GHz)
변조 방식: FHSS
호환 BLUETOOTH 프로파일[2)]:
　A2DP(Advanced Audio Distribution Profile)
　AVRCP(Audio Video Remote Control Profile)
　HFP(Hands-free Profile)
　HSP(Headset Profile)
지원 코덱[3)]: SBC[4)], AAC[5)]
지원하는 콘텐츠 보호 방식: SCMS-T
전송 범위(A2DP): 20 Hz - 20,000 Hz(샘플링 주파수 44.1 kHz)
동봉품:
　무선 스테레오 헤드셋(1)
　Micro-USB 케이블(약 50 cm)(1)
　참조 가이드(이 설명서)(1)
　빠른 사용 설명서(1)
　기타 도큐먼트(1세트)**

**1) 실제 범위는 장치 간 장애물, 전자레인지 주변의 자기장, 정전기, 수신 감도, 안테나 성능, 운영 체제, 소프트웨어 응용 프로그램 등의 요소에 따라 달라집니다.
2) BLUETOOTH 표준 프로파일은 장치 간 BLUETOOTH 통신 목적을 나타냅니다.
3) 코덱: 오디오 신호 압축 및 변환 형식
4) 서브밴드 코덱
5) 고급 오디오 부호화**

무선 스테레오 헤드셋

**전원: DC 3.7 V: 내장 리튬이온 충전지
무게: 약 80 g
사용 온도: 0 °C ~ 40 °C
정격 소비전력: 1.4 W
사용가능 시간:
　통신 시간(음악 재생시간 포함): 최대 9시간
　대기 시간: 최대 120시간
충전 시간:
　약 1.5시간
충전 온도: 5 °C ~ 35 °C**

리시버

**종류: 오픈에어형
드라이버 장치: 30 mm
주파수 응답특성: 10 Hz - 24 kHz**

마이크

**종류: 일렉트렛 콘덴서
지향성: 무지향성
유효 주파수 범위: 100 Hz - 4,000 Hz**

USB를 사용한 배터리 충전 시스템 요건

다음 운영 체제 중에서 한 가지가 사전 설치되어 있고 USB 포트가 탑재된 컴퓨터:

**운영 체제
(Windows를 사용하는 경우)
Windows® 8 / Windows® 8 Pro
Windows® 7
Home Basic / Home Premium / Professional / Ultimate
Windows Vista®(Service Pack 2 이상)
Home Basic / Home Premium / Business / Ultimate
Windows® XP(Service Pack 3 이상)
Home Edition / Professional / Media Center Edition 2004 / Media Center Edition 2005**

**(Macintosh를 사용하는 경우)
Mac OS X(버전 10.3 이상)**

디자인 및 주요 제원은 사전 통보 없이 변경될 수 있습니다.